



Filter Housing Installation Instructions

Thank you for purchasing a filter housing for your pre-filtration needs.

First, you will need to decide on a location for your new filter housing. This can be either above or below your counter top, depending on your needs. The location needs to be between your ionizer and your source water.

Install the cartridge in the housing by unscrewing the cap on the top of the housing and placing the cartridge inside. Be sure that the rubber gasket is facing up towards the cap and replace the cap by screwing it on tightly. (Very important, screw the cap on **tightly**, otherwise the pressure combined with a loose cap could cause leaking).

Turn off the source water. Cut the cold water supply line and press into the fittings on the side of the cap. Be sure to make a clean and straight cut on the tubing. These fittings are a quick connect style. To install the tubing, all you need to do is firmly push the lines into the openings and give a little tug to make sure that they are seated properly. If you look at the top of the cap you will see “in” and “out” labels above the fittings. The “in” needs to connect to the line running from the source water, and the “out” needs to run to the inlet on the ionizer.

Before hooking up to your ionizer, be sure to run water through the cartridge for 1-2 minutes until the water runs clear. This will help to flush out any media dust and insure good clean water. We recommend you flush replacement cartridges in this same manner.

Install the feed line from the outlet of your filter housing into the inlet of your ionizer and turn the water back on. You are now ready to enjoy cleaner, healthier, alkaline water!

If for some reason you need to disconnect the lines from any of these connections, first turn off the source water. Then turn on the ionizer or faucet momentarily to release any pressure in the system. Press down on the collet (or ring) around the connection where the tubing meets the connector. While holding this collet down, slide the tubing out of the fitting. It may be easier to use the back side of a butter knife or a small screw driver to hold the collet down. If you have issues with installation, please contact AlkaViva Customer Service at (775) 324-2400, Option 3.

For detailed instructions with pictures: Go to <http://www.alkaviva.net/pdf/install-housing-or-Spartan.pdf>

Watch this video: How to Replace and Properly Flush the Filter(s) in an External Single, Double, Triple Filter Housing - <https://vimeo.com/147909784>



Filter Housing Installation Instructions

Thank you for purchasing a filter housing for your pre-filtration needs.

First, you will need to decide on a location for your new filter housing. This can be either above or below your counter top, depending on your needs. The location needs to be between your ionizer and your source water.

Install the cartridge in the housing by unscrewing the cap on the top of the housing and placing the cartridge inside. Be sure that the rubber gasket is facing up towards the cap and replace the cap by screwing it on tightly. (Very important, screw the cap on **tightly**, otherwise the pressure combined with a loose cap could cause leaking).

Turn off the source water. Cut the cold water supply line and press into the fittings on the side of the cap. Be sure to make a clean and straight cut on the tubing. These fittings are a quick connect style. To install the tubing, all you need to do is firmly push the lines into the openings and give a little tug to make sure that they are seated properly. If you look at the top of the cap you will see “in” and “out” labels above the fittings. The “in” needs to connect to the line running from the source water, and the “out” needs to run to the inlet on the ionizer.

Before hooking up to your ionizer, be sure to run water through the cartridge for 1-2 minutes until the water runs clear. This will help to flush out any media dust and insure good clean water. We recommend you flush replacement cartridges in this same manner.

Install the feed line from the outlet of your filter housing into the inlet of your ionizer and turn the water back on. You are now ready to enjoy cleaner, healthier, alkaline water!

If for some reason you need to disconnect the lines from any of these connections, first turn off the source water. Then turn on the ionizer or faucet momentarily to release any pressure in the system. Press down on the collet (or ring) around the connection where the tubing meets the connector. While holding this collet down, slide the tubing out of the fitting. It may be easier to use the back side of a butter knife or a small screw driver to hold the collet down. If you have issues with installation, please contact AlkaViva Customer Service at (775) 324-2400, Option 3.

For detailed instructions with pictures: Go to <http://www.alkaviva.net/pdf/install-housing-or-Spartan.pdf>

Watch this video: How to Replace and Properly Flush the Filter(s) in an External Single, Double, Triple Filter Housing - <https://vimeo.com/147909784>