

VESTA ALKALINE WATER IONIZER OPERATION MANUAL

August 28, 2014



This new program allows you to adjust the settings on your Vesta ionizer to Hard, Normal, or Soft water. Instructions for Adjusting Settings start on page 15 and this setting is #F07 on page 17.

Note: There is no need to change any setting if your ionizer is working well.

Contact AlkaViva Technical Support at 775-324-2400 Option 2 if you have any questions.

FND type (GL988) USA NEW Program

	Descriptions	Prior US Program	New US Program Mod Request						
4	Plate Number Selection	<p>Only 9 plates available (locked)</p>	<div style="border: 2px dashed red; padding: 5px;"> <table border="0"> <tr> <td></td> <td>H => 5 plate</td> </tr> <tr> <td></td> <td>N => 7 plate</td> </tr> <tr> <td></td> <td>S => 9 plate</td> </tr> </table> </div>		H => 5 plate		N => 7 plate		S => 9 plate
	H => 5 plate								
	N => 7 plate								
	S => 9 plate								

Test Result



"H" 5 Plates



"N" 7 Plates



"S" 9 Plates