



# How to Replace the New H2 Smart Filters

## 1. Open Both Filter Doors.

- Press and hold the white button located at the bottom of the filter doors.
- While holding the white button, lift the filter door straight up.

## 2. Remove Old Filters

- Disconnect the wiring cable for each expired filter.
- Twist the expired filter counter clockwise and lift out.

## 3. Install New Filters

- Remove the protective sticker on the bottom of each filter.
- Insert the opening of the new Filter onto the base, located on the bottom of the Filter compartment.
- Make sure to align the Filter tabs with the slots in the Filter compartment base
- Twist clockwise until locked. You should NOT be able to lift it out. If the Filter is not fully twisted, it could cause a leak, or an error code on the LCD.
- Connect the wiring cable for each Filter. This will automatically reset the Filter counter to zero.

## 4. Close the Filter Doors.

- Line up the tabs of the Filter door with the slots located on both sides of the filter compartment and slide down until you feel/hear the filter door lock.

### Important:

If you have an earlier version of the H2 line with the reset buttons, then please follow the instructions from the filter replacement brochure. Smart Filters work in your ionizer. There is no need to connect the wire harness, just reset Filter counter as shown in fig 4 on page 18 of your manual.