



5 Micron Carbon Block for Reverse Osmosis System

Installation Instructions

- ✓ Install the cartridge into the filter housing by unscrewing the cap on the top of the filter housing and placing the cartridge inside. Remove plastic film prior to placing filter inside the housing.
- ✓ Be sure the rubber gaskets are in place, replace the cap and screw it down tightly. **NOTE:** It is *very important* to make sure the cap is screwed down tightly or the pressure inside the housing may cause a leak.
- ✓ Initial Flushing Instructions: Run water through the new filter until the water runs clear.

Important:

- ✓ Filter should not be used where the water is microbiologically unsafe, or with water of unknown quality without adequate disinfection before and/or after the filter.
- ✓ The "O" ring in the housing should be periodically replaced and/or lubricated to prevent leakage.
- ✓ Be sure to keep filter away from heat sources.
- ✓ Change filter yearly or when rated capacity expires, whichever comes first.
- ✓ Components of this filter are FDA approved.

Contents: 5M Carbon Block for R.O. System;
Item #7000311



5 Micron Carbon Block for Reverse Osmosis System

Installation Instructions

- ✓ Install the cartridge into the filter housing by unscrewing the cap on the top of the filter housing and placing the cartridge inside. Remove plastic film prior to placing filter inside the housing.
- ✓ Be sure the rubber gaskets are in place, replace the cap and screw it down tightly. **NOTE:** It is *very important* to make sure the cap is screwed down tightly or the pressure inside the housing may cause a leak.
- ✓ Initial Flushing Instructions: Run water through the new filter until the water runs clear.

Important:

- ✓ Filter should not be used where the water is microbiologically unsafe, or with water of unknown quality without adequate disinfection before and/or after the filter.
- ✓ The "O" ring in the housing should be periodically replaced and/or lubricated to prevent leakage.
- ✓ Be sure to keep filter away from heat sources.
- ✓ Change filter yearly or when rated capacity expires, whichever comes first.
- ✓ Components of this filter are FDA approved.

Contents: 5M Carbon Block for R.O. System;
Item #7000311