



Procedure for Resetting the Vesta

- 1. Set filter life to maximum (60).**
 - Turn off the Vesta using the power button on the bottom of the unit.
 - Wait 10 seconds.
 - Turn the power switch back on and immediately touch and hold the Menu button until the Vesta enters the setting adjustment mode (AL1 will appear on the display.)
 - Press the Alkaline button to cycle forward through the different functions until you reach F12.
 - Using the Acidic and/or Filter Reset buttons, change the setting for F12 to 60.
 - Use the Alkaline button to cycle forward to the next function, F13.
 - Using the Acidic and/or Filter Reset buttons, change the setting for F13 to 60.
 - Exit the setting adjustment mode by momentarily pressing the Menu button.
- 2. Reset BOTH filter counters.**
- 3. Set filter life back to normal.**
 - Touch and hold the Menu button until the unit enters the setting adjustment mode.
 - Use the Alkaline button to cycle forward to F12.
 - Using the Acidic and/or Filter Reset buttons, change the setting back to 35.
 - Use the Alkaline button to cycle forward to F13.
 - Using the Acidic and/or Filter Reset buttons, change the setting back to 35.
 - Momentarily press the Menu button to exit the setting adjustment mode.
- 4. Reset BOTH filter counters again.**
- 5. Unit has been reset and is ready for use.**